TECH TIPS

PRODUCT: DVD Home Theater System
TIP VERSION: DVD02-003
MODELS: HT-DL70D, HT-DL200P, HTDM150, HTDM550

SUBJECT: Dealer lock function

SYMPTOM: Our DVD has a dealer lock function that locks access to the open/close and power function.

REPAIR: Turn power on. Pressing and holding the "FUNCTION KEY" on the front panel for three seconds activates this function. If you press and hold the "FUNCTION KEY" for three seconds again, the dealer lock function will be released.

REMARKS: Our "2002" line of DVD home theater systems models will all have this function.